

# Direct Connect/Digidesign StreamManager v5.1.1cs10 for TDM and Real-Time AudioSuite (RTAS)

---

## What's New?

This new version of DirectConnect and Digidesign StreamManager applies to Pro Tools|24 MIX users only. It allows you to instantiate a second HTDM plug-in or combination of DirectConnect and HTDM plug-ins without the need for an empty SRAM chip. Previously there was a bug in the Digidesign StreamManager that would prevent you from instantiating more than one HTDM plug-in or any combination of DirectConnect and HTDM plug-ins without an empty SRAM chip available. A single SRAM chip is now able to handle up to 16 stereo DirectConnect or HTDM plug-ins in any order and any combination.

---

## System Requirements

DirectConnect and Digidesign StreamManager v5.1.1cs10 require a Pro Tools TDM or Pro Tools LE system running software version 5.1.1 or higher.

---

## Third Party Application Compatibility

DirectConnect and Digidesign StreamManager v5.1.1cs10 are fully compatible with all existing DirectConnect client applications on both Pro Tools TDM and Pro Tools LE platforms.

---

## Installation Instructions

**To install DirectConnect and Digidesign StreamManager v5.1.1cs10, please perform the following steps:**

- 1 Quit Pro Tools.
- 2 Remove the older version of DirectConnect from the System Folder/DAE Folder/Plug-Ins folder.
- 3 Move the DirectConnect with version number "5.1.1cs10" listed in the Get Info window of the file into System Folder/DAE Folder/Plug-Ins.
- 4 Remove the older version of Digidesign® StreamManager from System Folder/Extensions folder.
- 5 Move the Digidesign® StreamManager with version number "5.1.1cs10" listed in the Get Info window of the file into System Folder/Extensions. If you would like to use the lower 128 sample buffer, please use the file named "Digidesign® StreamManager\_128" with version number "5.1.1\_128cs10" listed in the Get Info window of the file. Do NOT use both versions of StreamManager simultaneously.
- 6 Reboot your CPU.

For more information about the general operation of DirectConnect, please refer to the DirectConnect portion of your Digi-Rack Plug-Ins Guide.